

EZY-FIT DIY Roller Shutters



















Installation Instructions

Face-Fit, Brick/Concrete Wall
AC Electric Motor, with Packer



This page is intentionally left blank.

Face-Fit on Brick/Concrete walls with AC Electric Motor

Qty.	Part	
Parts (provided with roller shutter)		
1	Pelmet complete with roller shutter system	
2	Shutter guide	
2	Bottom guide cap or	
1	Sill angle	
2	Packing profile (if needed)	
1	Control switch	
12	Wall plugs (6.5 x 35 mm)	
12	Screws (6 x 35 mm)	
12	Tek screws (if using packing profile)	
12	Hole caps	
6	Pop rivets (3.2 mm)	
1	Height/limit adjustment tool for motor	
1	Wiring instructions (for qualified electrician to use)	
1	Paper template	
Required tools (not included)		
1	6.5 mm drill bit	
1	10 mm drill bit	
1	6.5 mm Straight masonry bit or 6.5 mm SDS-plus masonry bit (if using hammer drill)	
1	12 mm Straight masonry bit or 12 mm SDS-plus masonry bit (if using hammer drill)	
1	Rivet gun	
1	Cordless drill/driver or Hammer drill	
1	Philips screw driver or Driver bit	

- Please ensure you have thoroughly read and understood these instructions and the safety notes before commencing installation.
- make sure that the roller shutter in the package has not sustained any major transport damage, and if so, photos must be taken and sent to us via email or post.
- The safety and installation instructions must be followed accurately. Failure to do so will result in a void warranty.
- These instructions are designed for you to easily install your roller shutter using simple tools. However, call us on 1800 633 136 if you are in any doubt about how to install and operate the roller shutter or about any safety issues.
- The wiring of 240 V AC Electric Motors should be conducted by a qualified electrician according to local and national standards and regulations.
- Wear personal protective equipment before you start to help avoid self-injury. For example: safety glasses, safety boots, ear plugs, hard hats, long sleeves, gloves, etc.
- The installation videos are also available on our website: www.ezyfitrollershutters.com.au