

# **EZY-FIT DIY Roller Shutters**

**Installation Instructions**

**Face-Fit**

















**Rendered Blueboard/Foam Wall  
AC Electric Motor, without Packer**



Videos and instructions available on our website:  
<http://www.ezyfitrollershutters.com.au>  
Free call: 1800 633 136

*This page is intentionally left blank.*


Rendered Blueboard/Foam walls with AC Electric Motor

Qty.	Part	
Parts (provided with roller shutter)		
1	Pelmet complete with roller shutter system	
2	Shutter guide	
2	Bottom guide cap	
1	or Sill angle	
2	Packing profile (if needed)	
1	Control switch	
12	Tek screws (if using packing profile)	
12	Timber screws	
12	Hole caps	
6	Pop rivets (3.2 mm)	
1	Height/limit adjustment tool for motor	
1	Wiring instructions	
1	Paper template	
Required tools (not included)		
1	6.5 mm drill bit	
1	10 mm drill bit	
1	12 mm drill bit	
1	Rivet gun	
1	Cordless drill/driver	
1	Philips screw driver or Driver bit	

- Please ensure you have thoroughly read and understood these instructions and the safety notes before commencing installation.
- make sure that the roller shutter in the package has not sustained any major transport damage, and if so, photos must be taken and sent to us via email or post.
- The safety and installation instructions must be followed accurately. Failure to do so will result in a void warranty.
- These instructions are designed for you to easily install your roller shutter using simple tools. However, call us on 1800 633 136 if you are in any doubt about how to install and operate the roller shutter or about any safety issues.
- The wiring of 240 V AC Electric Motors should be conducted by a qualified electrician according to local and national standards and regulations.
- Wear personal protective equipment before you start to help avoid self-injury. For example: safety glasses, safety boots, ear plugs, hard hats, long sleeves, gloves, etc.
- The installation videos are also available on our website: [www.ezyfitrollershutters.com.au](http://www.ezyfitrollershutters.com.au)



1. Unwrap the pelmet box and guides and put them on the ground



Step 2: Remove the front cover by sliding it out.



Step 3: Make sure metallic legs are in place on both sides. If not, slide them in place.



Step 4: Place one of the guides on the wall, keeping the bottom flush with the bottom of the opening.




Step 5: Use the provided paper template to estimate the final position of pelmet box and securing points.  
Fold the template and place the guide over the hatched area



Step 6: Mark the securing point for pelmet box.





Step 7: Mark at least 3 fixing points on the guide approx. 100 mm from the top and bottom and distribute the holes approx. 400~500 mm apart making sure you place the holes over the bullnose.




Step 8: Put the guide back on the ground and use the 6.5 mm drill bit to drill holes all the way through on the points you have marked. Do the same on the other side's guide.





Step 9: Then change the drill bit to 10 mm and only drill through the front part of shutter guide on all holes.




Step 10: Put one of the guides on the wall and mark the holes on the wall.



Step 11: Use the 3 mm bit to drill pilot holes for securing points including the pelmet fixing point.




Step 12: Secure the guide temporarily by using just two screws at the top and the bottom.




Step 13: Put the other guide on the wall and space it so that the back to back of the guides is the same as pelmet box's width. Measure the top and bottom distance to make sure the guides are parallel.




Step 14: Use the template for the other side as well to mark the securing point for pelmet box.  
Also mark the guide fixing points on the wall.



Step 15: Use the 3 mm bit to drill pilot holes for securing points



Step 16: Unscrew and put the other guide back on the ground.



Step 17: Slide the guides in place and secure them by rivets using the pre-drilled holes.




Step 18: Slide the bottom caps in place if sill angle is not required.  
If sill angle is required, secure it using rivets and pre-drilled holes.





Step 19: Shutter is now ready to be secured on the wall. Put one hand underneath the pelmet box and the other holding the guide. Avoid tilting the guides as this may break the legs.




Step 20: For lifting the shutter, two people need to hold the assembly on both sides and lift at the same time to place it on the wall. Then slide it up in place while pushing against the wall




Step 21: Secure the guides using the provided screws.



Step 22: After putting all the screws in, use the plastic caps to cover the holes.




Step 23: Roller shutter is installed now. Ask a “Qualified Electrician” to wire the motor for you according to the instructions provided with the roller shutter.




Step 24: With the shutter unrolled, secure the pelmet box.





Step 25: Put the front cover in place by sliding it in and secure it using the provided rivets and pre-drilled holes.



Step 26: Enjoy your roller shutter!